



UK price list 2016



147w x 135h



small door

211w x 135h



medium door


211w x 225h



large door


perforated paper labels available with word template

211w x 375h




A4 insert
Portrait

298w x 288h




A4 insert
Landscape

298w x 499h



A3 insert
Portrait

422w x 375h



A3 insert
Landscape

windows are clear
sizes in (mm)

Door & Wall (refer to page 4 for pricing)

211w x 1422h



A4 insert
Portrait

298w x 1422h



A4 insert
Landscape

298w x 1422h



A3 insert
Portrait

422w x 1422h




A3 insert
Landscape

windows are clear
sizes in (mm)


Monolith Signs (refer to page 4 for pricing)

Projecting Signs

(refer to page 4 for pricing)



sizes in mm



Suspended Signs (refer to page 4 for pricing)

sizes in mm

Standard Finishes

metallic SERIES

metallic foil series shown with standard colour bodies




frosted SERIES

frosted series shown with standard colour bodies





natural SERIES

natural foil series shown with standard colour bodies











pastel SERIES



truly lockable insert sign

no tools required



- 1 Empty paper insert sign
- 2 No apparent way in
- 3 Push header panel to the right firmly, until it 'clicks' into place
- 4 Push header panel upwards with two hands until it 'clicks'
- 5 Window opens (and is removable for internal cleaning)
- 6 Perforated paper label inserted & window closed
- 7 Header panels pushes down until it 'clicks'
- 8 Header panels pushes left until it 'clicks'
- 9 Sign is complete and locked again

